

Fig.1




Fig.2




Fig. 4




Fig.5




FIGURE 110860

Fig. 6




FIG. 7

Fig. 7




Fig. 8





Fig. 9



[illegible]

Fig. 10

















id5	id4	CE11	By Printer	CE12	By Copy or Page
No Marked Page					
Marked Page Head					
Marked Page End					
Marked Page Head + End					

FIGURE 11

Fig. 11




Fig. 12




FIGURE 13

Fig. 13

The 'Print' dialog box contains the following elements:

- Printer Section:**
 - Name (N): id21
 - Status: Ready
 - Type: LP-100
 - Where: LPT1:
 - Comment:
 - Properties (P) button
- Print Range Section:**
 - Print Range:
 - ☒ All (A)
 - ☐ Current Page (E)
 - ☐ Pages (G):
 - Enter page numbers and/or page ranges.
For example, 1,3,6, 4-8.
- Copies Section:**
 - Number of copies (C): id23
 - ☒ Collate (T)
 - Diagram showing page sequence: 1, 2, 3, 1, 2, 3
- Print what (W):** id22 (set to 'Document')
- Zone (Z):** (set to 'All')
- Buttons:** Options (O)..., OK, Close
- Footer:** ☐ Print to file (L)

Fig. 14




Fig. 15




Fig. 16




Fig. 17




Fig. 18

Output Resources	Page Numbers
Printer 60	1, 2, 3, 4
Printer 70	5, 1, 2, 3, 4, 5, 1, 2
Printer 80	3, 4, 5, 1, 2, 3, 4, 5

Fig. 19

Output Resources	Page Numbers
Printer 60	1, 2, 3, 4, 5
Printer 70	1, 2, 3, 4, 5, 1, 2, 3, 4, 5
Printer 80	1, 2, 3, 4, 5

Fig. 20




FIG. 21

Fig. 21




Fig. 22




Fig. 23




Fig.24





Fig.25

PD

GROUP NAMES	PRINTER NAMES	COMMENTS
MONOCHROMATIC LASER	LP-100,LP-200,LP-300	...
INK JET	PM-700C,PM-750C,PM-770C	...

Fig. 26



100611 1100660

Fig. 27

The image shows a 'Print' dialog box with the following sections and controls:

- Printer:**
 - Name (N):
 - Status: ☒ Distributed Printing ☐ Properties (P)
 - Type: Ready
 - Where: LP-100
 - Comment: LPT1:
- Print Range:**
 - ☒ All (A)
 - ☐ Current Page (E)
 - ☐ Selection (S)
 - ☐ Pages (G):
 - Enter page numbers and/or page ranges.
For example, 1,3,6, 4-8.
- Copies:**
 - Number of copies (C):
 - ☒ Collate (T)
 - Diagram showing page sequence: 1, 2, 3, 1, 2, 3
- Print what (W):**
- Zone (R):**

Labels in the diagram point to specific elements:

- id151 points to the 'Print' title bar.
- WN16 points to the 'Printer' section.
- id153 points to the 'Properties (P)' button.
- id152 points to the 'OK' button.

Fig. 28




Fig. 29





Fig. 30



1006111100650

Fig. 32

Printer Group

Group Name (G):

Monochromatic Laser

Printers (P):

LP-100

LP-200

LP-300

Select Option

☒ Functionality Preference (F) ☐ Speed Preference (S)

Paper Settings

Paper Size (S):

A4(210 X 297 mm)

B5(182 X 257 mm)

A4(210 X 297 mm)

A3(297 X 420 mm)

fd14

id111

fd15

id141

MN2

fd16

id113

FIG. 33

Fig. 33

Printer Group

Group Name (G):

Monochromatic Laser

Printers (P):

LP-100
LP-200
LP-300

fd14

id111

id113

Select Option

☐ Functionality Preference (F)
☒ Speed Preference (V)

Paper Settings

Paper Size (S):

A4 (210 X 297 mm)

B5 (182 X 257 mm)

A4 (210 X 297 mm)

fd15

MN2

fd16

Fig.34

Printer Group

Group Name (G):
Monochromatic Laser

Printers (N):
LP-100
LP-200
LP-300

Select Option
☒ Functionality Preference (X) ☐ Speed Preference (Y)

Paper Settings
Paper Size (Z):
A3 (297 X 420 mm)

id113

id141

[illegible]

Fig. 35

Distributed Printing Properties

Printer

Printer Group

Group Name (G): Monochromatic Laser

Comment:

Printers (N):

☒ LP-100

☒ LP-200

☐ LP-300

Number of Printers: 2

Group Settings (L)...

☐ Distribute Evenly to Printers (E)

Select Option

☒ Functionality Preference (X) ☐ Speed Preference (Y)

Paper Settings

Paper Size (Z): A4 (210 X 297 mm)

Orientation

☒ Portrait (P) ☐ Landscape (L)

☐ Double-faced Print (W)

Paper Type (M): Plain

Color

☒ Color (C) ☐ Black (B)

Resolution

☒ Fast (S) ☐ Fine (Q)

Group Name:

Color

Fast

Single-faced

Number of Printers: 0

OK Cancel Help

PF04F99 *

Fig. 36

Printer Group

Group Name (G):

Monochromatic Laser

Printers (N):

☒ LP-100
☒ LP-200
☐ LP-300

Select Option

☒ Functionality Preference (F)
 ☐ Speed Preference (S)

Paper Settings

Paper Size (Z):

id141

A4(210 X 297 mm)

85(182 X 267 mm)

A4(210 X 297 mm)

43(297 X 423 mm)

MN2

cbx

id113

Fig. 37




Fig.38




Fig. 39




Fig.40

Output Resources	Page Numbers
Printer 60	1 st page、2 nd page、3 rd page
Printer 70	1 st page、2 nd page、3 rd page
Printer 80	1 st page、2 nd page、3 rd page